



Lubrication Positions




Gamma 090- | 120- | 160- | 220- | 280-ZSS



Lubrication of guiding carriages 1+2 and 3+4 (**F**).

The guiding carriages must be lubricated through both funnel grease nipples on either side.


Gamma 90-ZSSD



Lubrication of guiding carriages 1, 2, 3 and 4 (**F**).

Guiding carriages 1 and 3 must be lubricated **individually** through both funnel grease nipples on side C, guiding carriages 2 and 4 through both funnel grease nipples on side D.


Gamma 120-ZSSD, SP150



Lubrication of guiding carriages 1, 2, 3 and 4 (**F**).

Guiding carriages 1 and 3 must be lubricated **individually** through all four funnel grease nipples on side C (two funnel grease nipples per carriage), guiding carriages 2 and 4 through all four funnel grease nipples on side D.

Gamma 120-ZSSD, SP250




Lubrication of guiding carriages 1+2 and 3+4 (**F**).

The guiding carriages must be lubricated through both funnel grease nipples on either side.

Lubrication Points for Gamma Linear Units with Toothed Belt Drive


Gamma 160- | 220- | 280-ZSSD



Lubrication of guiding carriages
1+2 and 3+4 (**F**).

The guiding carriages must be lubricated
through both funnel grease nipples on either
side.


Gamma 090- | 120- | 160-ASH



Lubrication of guiding carriages
1+2 and 3+4 (**F**).

The guiding carriages must be lubricated
through both funnel grease nipples on either
side.

Gamma 220-ASS



Lubrication of guiding carriages
1+2 and 3+4 (**F**).

The guiding carriages must be lubricated
through both funnel grease nipples on either
side.